TERMOZETA

RAFFRESCATORE D'ARIA
AIRZETA ICE
cod. TZAZ10

MANUALE D'ISTRUZIONI

Vi ringraziamo per la preferenza accordata avendo scelto un prodotto TERMOZETA.

Vi preghiamo di leggere attentamente le informazioni contenute in questo manuale, in quanto Vi forniscono a sfruttare al meglio le caratteristiche di questo prodotto.
Il presente libretto è parte integrante dell'apparecchio e deve essere letto attentamente prima dell'utilizzo perché fornisce importanti indicazioni riguardanti la sicurezza di installazione, d'uso e di manutenzione. Conservarlo quindi con cura

Cordialmente
Lange Distribution S.r.l.

Leggere attentamente questo manuale d'istruzioni poiché all'interno si sono importanti informazioni sulla sicurezza, l'uso e la manutenzione dell'elettrodomestico. Conservare il manuale per consultazioni future.

AVVERTENZE GENERALI

1. Utilizzare quest'apparecchio solo come descritto nel presente manuale.
2. Non fare un uso improprio del prodotto.
3. Qualsiasi altro uso non consigliato dal costruttore può causare incendi, scosse elettriche o incidenti a persone.
4. Questo prodotto non è un giocattolo. I bambini devono essere costantemente supervisionati al fine di assicurarsi che non lo giochino.
5. Questo apparecchio può essere usato da bambini dagli 8 anni in su e da persone con ridotte capacità fisiche, sensoriali o mentali, oppure con mancanza di esperienza e conoscenza, se hanno potuto beneficiare, attraverso l'intermediazione di una persona responsabile della loro sicurezza, di una sorveglianza o di istruzioni riguardanti l'uso del condizionatore e quindi hanno capito i possibili rischi.
6. Disinserire l'alimentazione dalla rete in caso di non utilizzo o pulizia.
7. In caso di anomalie spegnere subito l'apparecchio, non tentare di ripararlo, e portarlo al centro assistenza tecnica autorizzato.
8. Non smontare o sostituire i pezzi da soli, questo potrebbe influire sulla sicurezza del prodotto.
9. Non toccare il cavo di alimentazione con le mani umide; rischio di scossa elettrica!
10. Non inserire oggetti nelle griglie dell'apparecchio. Può portare a perdite, corto circuito e danni al prodotto.
11. Non spruzzare sostanze infiammabili o pesticidi attorno al prodotto, potrebbe danneggiare il prodotto.
12. Non utilizzare l'apparecchio in presenza di fili o spine danneggiati. Non tentare di cambiare il cavo di alimentazione da sé.

13. Se il caso di alimentazione è danneggiata dovrà essere sostituito dal produttore, dal suo rivenditore o da una persona altamente qualificata onde evitare rischi.
14. Non piegare e appoggiare oggetti pesanti sul cavo di alimentazione.
15. Spegnere l'interruttore ed estrarre la spina prima di fare manutenzione o muovere l'apparecchio. Staccare sempre la spina quando l'apparecchio non è in uso.
16. Per disinvestire l'apparecchio, premere il tasto ON/OFF e rimuovere la spina dalla presa. Tirare solo la spina. Non tirare il cavo.
17. Non versare acqua sopra al prodotto; rischio di corto circuito e danni al prodotto.
18. Non lasciare a lungo la mandata dell'aria diretta verso un bambino; non è salutare.
19. Dopo aver tolto l'imballaggio, assicurarsi dell'integrità dell'apparecchio; in caso di dubbio non utilizzarlo e rivolgersi a personale professionalmente qualificato. Gli elementi d'imballaggio (sacchetti di plastica, polistirolo espanso, chiodi, ecc.) non devono essere lasciati alla portata di mano di bambini in quanto potenziali fonti di pericolo; ma vanno smaltiti secondo le norme vigenti negli appositi contenitori per la raccolta differenziata.
20. Questo apparecchio è destinato solo all'impiego domestico, per ventilare e raffrescare ambienti interni secondo le modalità indicate in queste istruzioni; non utilizzarlo per altro scopo.
21. Prima di collegare l'apparecchio controllare che i valori di tensione riportati sulla targa dati corrispondano a quelli della rete elettrica.
22. Questo apparecchio non è destinato a essere fisso funzionante per mezzo di un temporizzatore esterno o con un sistema di comando a distanza separato, per evitare il rischio di incendio nel caso l'apparecchio sia coperto o sia posizionato in modo non corretto.

23. Prima di oggni utilizzo verificare che l'apparecchio sia in buono stato, che il cordone elettrico non sia danneggiato: in caso di dubbio rivolgersi a personale professionalmente qualificato.
24. La presa di corrente deve essere facilmente accessibile in modo da poter disinserire con facilità la spina in caso di emergenza.
25. Posizionare l'apparecchio lontano da fonti di calore (ad es. fornelle libere, fornelle gassoc.), contenitori di liquidi (ad esempio, vasche da bagno, docce, lavelli ecc.) per evitare schizzi d'acqua o che vi possa cadere (distanza minima 2 metri) fiamelle, tessuti (tende, ecc.) o materiali volatili che possano ostruire la griglia di aspirazione; verificare che anche la parte anteriore sia agombra da materiali volatili (pallavere, ecc.).
26. Non infilare alcun utensile o le dita fra le maglie delle griglie di protezione della ventola
27. Non utilizzare l'apparecchio con temperatura ambiente superiore a 40°C.
28. Non usare l'apparecchio se non funziona correttamente o se sembra danneggiato: in caso di dubbio rivolgersi a personale professionalmente qualificato.
29. Assicurarsi che la ventola funzioni correttamente: nel caso contrario spegnere l'apparecchio e farlo controllare da personale professionalmente qualificato
30. Se l'apparecchio non è in funzione togliere la spina dalla presa di corrente.
31. Scollegare sempre l'apparecchio dalla presa di corrente prima di assemblare, smontare, riempire o svuotare il serbatoio, e prima di pulire i filtri e l'apparecchio.
32. Non lasciare l'apparecchio esposto agli agenti atmosferici (sole, pioggia, ecc.).
33. Non bocciare l'apparecchio con mani o piedi bagnati.
34. Non tirare il cavo per spostare l'apparecchio.
35. Non spostare l'apparecchio quando è in funzione

36. Non utilizzare presa cti corrente volianti oppure cavi danneggiati.Non toccare incautatiolo il prodotto quando è funzione
37. Non tirare il cavo d'alimentazione o l'apparecchio stesso per disinserire la spina dalla presa di corrente.
38. Scollegare dalla presa di corrente prima di riempire il serbatoio.
39. Non toccare il cavo di alimentazione con le mani bagnate, in modo da evitare shock elettrico.
40. Assicurarsi che il pogrip impianto domestico sia conforme alla specifiche elettriche dell'unità.
41. In caso di malfunzionamento, scollegare dalla presa di corrente in modo da evitare qualsiasi danno o pericolo.
42. Non palire, cuprire o spostare l'unità quando essa è collegata alla presa di corrente.
43. Posizionare su una superficie stabile e piatta, al fine di garantire efficienza e longevità della macchina.
44. Poiché l'unità presenta una elevata capacità di evaporazione di aria, è necessario che essa non provochi alterna ostruzione, in modo da evitare danni o malfunzionamenti.
45. Non mettere alcun oggetto pesante sul corpo del prodotto e, le prese d'aria devono essere coperte.
46. Non utilizzare l'unità in ambienti ove sono presenti materiali infiammabili o esplosivi, evitare l'esposizione alla luce solare.
47. L'unità deve poggiare su uno superficie stabile e orizzontale, in modo che essa non abbia la possibilità di cadere e danneggiarsi.
48. Dopo aver riempito il serbatoio, non toccare il corpo del condizionatore, ed assicurarsi che le proprie mani siano asciutte. L'unità non deve essere indirizzata o spostata per evitare la fuoriuscita di acqua dal serbatoio.
49. La quantità di acqua non deve eccedere il limite massimo consentito. In caso di fuoriuscita di acqua, scollegare immediatamente dalla presa di corrente ed asciugare. E' preferibile attendere circa 24 ore prima di ricollegare la macchina.
50. Non usare in ambienti umidi come bagni, piscine, etc.
51. La quantità di acqua non deve eccedere il limite minimo e massimo consentito per un corretto funzionamento.
52. Non posizionare accanto a pareti, finestre, tende o altri spazi chiusi e possibile l'aspirazione delle prese d'aria.
53. Questo prodotto è concepito per essere utilizzato in ambienti in cui la temperatura è compresa tra 0°C e 40°C. Per una corretta purificazione dell'aria, è necessario cambiare spesso l'acqua nel serbatoio. In caso di utilizzo nella stagione invernale, riempire il serbatoio con acqua tiepida.
54. L'unità ha una eccellente capacità di umidificazione, perciò è sconsigliato l'uso in luoghi chiusi, in cui si è un pessimo ricambio d'aria. In caso, non utilizzare l'umidificazione.
55. In caso di inattività prolungata, assicurarsi che acqua non sia fuoriuscita dal serbatoio, in caso asciugare.
56. Quando si pulisce il corpo dell'unità, non utilizzare agenti abrasivi o chimici in modo da non danneggiare le parti in plastica.
57. Quando viene consumata o trasportata, l'unità deve essere completamente esaurita, in modo da evitare spiacevoli odori.
58. Se il cavo è danneggiato, deve essere sostituito da un elettricista qualificato.
59. Non tentare di riparare da soli.
60. Non lasciare che l'unità venga utilizzata da persone diversamente abili o da bambini, è necessario una stretta supervisione.
61. Questo apparecchio non è destinato all'uso da parte di persone con la fisica ridotta, sensoriali o mentali, o mancanza di esperienza e conoscenza, a meno che non siano controllati o istruiti all'uso dell'apparecchio da una persona responsabile della loro sicurezza. I bambini devono essere sorvegliati per assicurarsi che non giochino con l'apparecchio.

FUNZIONI

1. Per creare la umidificazione viene evitata l'acqua dal serbatoio con una pompa, viene pulitola in alto e viene fatta passare attraverso un tampone rotante.Controllo elettronico della funzioni del prodotto.
2. Velocità regolabile: ALTA, MEDIA, BASSA.
3. Modalità di ventilazione: NATURALE, NORMALE, NOTTURNA.
4. Il prodotto attraverse l'utilizzo di cristalli ghiacciati, abbassa la temperatura ambiente ed aumenta la umidità relativa.
5. Grande angolo di esplosione dell'aria: Oscillazione delle alette verticali automatica e posizionamento manuale per le alette orizzontali.
6. Telecomando ad ampio angolo di trasmissione.
7. Filtro dell'aria e tampone rimovibili e facili da pulire.

INSTALLAZIONE

Montaggio delle ruote
Rivolcare il prodotto su un panno morbido per evitare che si graffi. Prendere le 4 ruote in dotazione ed avvitarle nei fori posti sul fondo del prodotto, utilizzando una chiave inglese.Passare le ruote con il freno di fronte, e le altre posizionarle

Riempimento del serbatoio
1. Estrarre il serbatoio dal prodotto.
2. Riempire il serbatoio con acqua pulita e fredda. Assicurarsi che il livello dell'acqua sia tra le indicazioni di minimo ed il massimo.
3. Per aumentare l'effetto refrigerante inserire le inalbaccie del ghiaccio nel serbatoio dell'acqua, dopo che si è creato il ghiaccio all'interno.
4. Chiudere il serbatoio dell'acqua.

ATTENZIONE

1. Assicurarsi che il prodotto sia scollegato dalla rete elettrica prima di riempire o rabbboccare il serbatoio dell'acqua.
2. Immettere unicamente acqua nel serbatoio. Non aggiungere prodotti chimici od altri additivi.
3. Utilizzare solo acqua fresca o pulita per il serbatoio dell'acqua.
4. Assicurarsi che il livello di acqua nel serbatoio stia tra il min e max indicato sul serbatoio.

Estrarre il serbatoio | Inserimento della inalbaccie | Montaggio ruote

LTA.OZ.DEL PRODOTTO

Posizionare il prodotto su una superficie stabile e piana ed collegare la spina alla presa di corrente. Le luci del ventilatore si accende ed il prodotto entra in modalità standby.
Orientare le alette orizzontali a mano come desiderato.
Premere il tasto ⏻ , la velocità dell'aria predefinita è a livello medio. Riprendendo il tasto il prodotto entra in stand-by.

1. **Tasto velocità** (⏻): Premendo questo tasto il prodotto varierà la velocità di ventilazione partendo dal livello medio secondo la sequenza:
   → MEDI → HIGH → LOW →
2. **Tasto modalità** (⏻): per modalità prampoiprata e la modalità NORMALE. Premendo questo tasto la modalità di ventilazione passa da NORMALE a NATURALA e NOTTURNA.
3. **Tasto oscillazione** (⏻): premendo questo tasto per attivare l'oscillazione delle alette verticali. L'indicatore di oscillazione è accesa. Premere di nuovo il tasto per bloccare l'oscillazione
4. **Tasto Timer**: premendo questo tasto per determinare il tempo raggiunto il quale

il prodotto smette di funzionare. Il tempo selezionabile varia da 0 a 8 ore. Ogni pressione del tasto incrementa il tempo di un ora.

5. **Tasto freddo** (⏻) premere questo tasto per ottenere aria più fredda in uscita dal prodotto. Accertarsi di avere riempito la inalbaccie del ghiaccio nel serbatoio per ottenere un migliore risultato. Premendo di nuovo il tasto la funzione si disattiva.
6. **Umidificazione** (⏻) premendo questo tasto il prodotto emetterà vapore anche alla bassa velocità.
7. **Tasto bersaaaaaaa** (⏻): Premere il tasto per attivare la bersaaaaaa.Premendo di nuovo la funzione si disattiva.

USO DEL TELECOMANDO

Il telecomando utilizza una batteria modello CR2025 (3V). Utilizzare sempre questa tipo di batteria

Nota: Quando le batterie si esauriscono, attenersi ai regolamenti che regolano lo smaltimento di questi rifiuti speciali

USO DELLE MATTONELLE DI GHIACCIO

Diminuisce la temperatura dell'acqua contenuta nel serbatoio. Quindi fare attenzione nel suo utilizzo.
Modo d'uso

a. Aggiungere l'acqua nella mattonella di ghiaccio, fare attenzione a non superare livello massimo. Riporre la mattonella di ghiaccio nel freezer per formare il ghiaccio.
b. Dopo aver riempito di acqua la mattonella del ghiaccio, After put clean water into the ice box, pls make sure it is cleanliness.
c. Contenuto della mattonella del ghiaccio deve essere tenuto lontano dai bambini e non è ingestibile.

CONSERVAZIONE E MANUTENZIONE

Attenzione: Spegnere il rifrescatore e disconnettetlo sempre dall'alimentazione elettrica prima di effettuare ogni operazione. Pulire il prodotto almeno una volta la settimana. Svuotare completamente il serbatoio o riempirlo con acqua fresca.
Se non si intende utilizzare il prodotto per lunga tempo, assicurarsi che tutte le parti siano asciutte attraverso la ventilazione per circa 30min, prima di riporre il prodotto.
Spegnere il prodotto e disconnettetlo dalla alimentazione elettrica. Svuotare il serbatoio Pulire con un panno asciutto.
Tagliare il tampone a rete d'aqua e pulirlo sotto un debole getto d'acqua. Riposizionare il filtro nel prodotto. Proteggere il prodotto con una coperta od una busta di plastica prima di riporlo. Avvolgere il cavo di alimentazione e fare attenzione che sia posizionato lontano dal pavimento.
Riporre il prodotto in un posto asciutto e al riparo dai raggi del sole.
Pulire le superfici del prodotto con un panno asciutto. Non usare prodotti chimici o corrosivi per la pulizia.

Rimuovere due viti | Sostituire dal tampone filtro | Sostituire dal filtro di carbo

La frequenza di pulizia del filtro dipende dalla quantità dell'aria e dell'acqua presente nel serbatoio. Consequpe pulire il filtro almeno ogni due mesi.
Pulire filtro sotto l'acqua corrente
Svuotare il serbatoio e sostituire l'acqua almeno ogni settimana.
Per ottenere «ragiol» qualità fai assegnare il filtro dopo ogni uso del prodotto.
Assemble functioners per 15minuti spegnendo la funzione refreddamento

DATI TECNICI

Voltaggio: 220-240V~ 50Hz
Potenza assorbita: 65W

Informazioni del prodotto			
Portata massima d'aria	l	1,25	m³/min
Pressione dell'aria del ventilatore	P	0x121	Pa
Valore di resistenza	Ev	0,34	(m³/min)²/P
Consumo elettrico in modo attivo	Pon		W
Livello di potenza sonora del ventilatore	Lwa	65,0	dB(A)
Velocità massima dell'aria	C	1,23	m/s
Norme di misura per il valore di energia	IEC 60879:1986 (ed.1.0)/EN		
Riferimento per ulteriori informazioni	Contatto Fornitore		

TERMOZETA

AIR COOLER
AIRZETA ICE XL
cod. TZAZ10

INSTRUCTION MANUAL

Please READ and RETAIN for future reference

SAFETY WARNINGS

1. After removing the packaging, make sure the appliance in case of doubt, do not use it and contact a qualified technician . The packing elements (plastic bags , polystyrene foam, nails, etc.) Must not be left within reach of children as they are potential sources of danger , but must be disposed of in accordance with regulations in the appropriate containers for recycling.
2. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved.
3. This appliance is designed for domestic use , to ventilate and cool interiors in the manner specified in these instructions . Do not use it for any other purpose.
4. Before connecting the appliance, check that the voltage printed on the nameplate correspond to those of the power grid . In case of incompatibility between the plug and the plug of the appliance ,have the socket replaced with attract suitable type by a qualified professional , who finds that the section of the cord is suitable for the power absorbed by the appliance . In general it is not advisable to use adapters and / or extension . If their use is absolutely necessary , need comply with current safety standards and scope of current lamps ,(must not be less than the maximum of the unit .
5. This device is not intended to be operated by means of an external timer or with a separate remote control system , to avoid the risk of fire in case the device is covered or is positioned incorrectly .
6. Do not connect the appliance to thermal control systems or programmer or timer or other device that can automatically turn the unit on , thus avoiding the risk of damage to persons, animals or things.

7. Before each use, check that the equipment is in good condition , that the wiring is not damaged ; in case of doubt, consult a qualified professional .
8. The socket must be easily accessible so you can easily disconnect the plug in case of an emergency .
9. Place the unit away from : heat sources (eg . flames, stove gas etc) containers of liquids (eg. bathtubs showers sinks , etc.) to prevent splashes of water or you can fall (minimum 2 meters) windows, textiles (curtains, etc.) or volatile materials that may obstruct the air intake grille , and check that the front is free from volatile materials (dust, etc.) .
10. Do not insert any tool or your fingers between the mesh grilles protect the fan
11. Do not use the device if ambient temperature is above 40 ° C.
12. Do not use the appliance if it does not work properly or appears to be damaged in case of doubt, consult a qualified professional .
13. Make sure the fan is working properly otherwise turn off the unit and have it checked by qualified personal only .
14. If the appliance is not in use , remove the plug from the socket .
15. Always disconnect the appliance from the electrical outlet before assembling, disassembling , fill and empty the tank , and before cleaning the filters and the unit.
16. Do not leave the appliance exposed to atmospheric agents (sun, rain, etc.) .
17. Do not touch the appliance with wet hands or feet .
18. Do not pull he cable to move the unit . Do not pull the power cord or the appliance itself to remove the plug from the socket .
19. Do not move the appliance when in use .
20. Don't leave product unattended when operating.Unplug the product when not in use.
21. Do not immerse cord, plug, or any part of the appliance in water or other liquids. Risk of electric shock.

22. Unplug the wire connector before fill into water to ensure safety.
23. Do not touch the wire connector with the wet hands, in order to avoid the electricity shock to be hurt .
24. If do not to use for a long time, please unplug the wire connector in order to avoid any damage to the product.
25. Do not clean, protect and move the product when power connected .
26. Please put the unit at the correct place when using the freeze function , otherwise will effect the normal operation and product life (The electricity may burn if serious).
27. As this product have the high speed operated wind wheel, the air outlet must not be obstructed in order to avoid any hurts or any damages to the machine .
28. Do not place any heavy objects on the top of the air cooler. The air outlet must not be obstructed.
29. Do not use the product under the flammable and explosive environment and avoid to put under the sun for a long time .
30. Please put the product horizontally, do not put it slant or any unstable place, in order to avoid product fall down to make any damages o the machine or pads .
31. After putting into the water, do not touch the body, do not be slant when move it, do not move by side to avoid overflow .
32. Do not overturn when used to avoid accident. If water inside accidentally overflow, should unplug the wire connector , until 24 hours dry enough to star machine again .
33. Do not use the product in the environment of bathroom, swimming, and shower nozzle .
34. The water tank ability cannot over the maximum and below the minimum .
35. Do not put the product near the wall, curtain etc, otherwise, may block the air, effect the wind volume .
36. This product is suitable for use under 0 degree to 40 degree, do not put under the high temperature and low temperature. As the

product purify the air, pay attention to change the water; if use this product in winter, under 0 degree, had better to use the warm water, absorb the rest water in time after used.
37. Don't insert any object in the openings and grilles of the product. Don't cover the product.
38. The product has effective humidification function. So please do not use in sealed place; if in sealed place, do not use humidification function.
39. Please absorb the water and dry the water tank if not to use for a long time to avoid become smelly .
40. If clean the outside board , please use wet cloth (with little mild detergent to clean, do not use the corrosive or solvent detergent to clean. Do not pull the water to the machine).
41. If stored or shipped, should dry to pack, to avoid evaporator insist or to be smelly .
42. If the wire is damage, must change by our professional repair staffs .
43. Non-professional or without authorization person cannot repair or remake it.
44. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety .
45. Children should be supervised to ensure that they do not play with the appliance.
46. The supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
47. If the power cable is damaged it must be replaced by the supplier, or by its Service Department or anyone by a person with similar qualification, in order to avoid any risk.
48. Before maintenance and cleaning the product, disconnect it from

the power supply .
49. Don't area the product outdoors and dont let him exposed to atmospheric agents .
50. Place the base of the product on a stable flat and dry surface.
51. Don't use mobile sockets or damaged cables .
52. Only plug the appliance into suitable, easily accessible, earthed mains connections. Make sure that the voltage of the power source is the same as that specified on the rating plate. The use of an incorrect connection voids the warranty .
53. Never pull the power cable, or the product itself, to disconnect it from main supply .
54. Always unplug completely the power cable, to avoid overheating .
55. The power inlet must be easily accessible to allow a fast disconnection from the main supply .
56. When discontinuing the product hand firmly the plug, to avoid electrical shock, or fire.
57. Never open or try to repair the product to avoid the risk of electrical shock. Refer to the dealer or to the Service .
58. Do not let the power cord come into contact with the metallic parts of the Moka coffee maker when in operation .
59. Before connecting the appliance, please noise sure that the voltage indicated on the identification plate corresponds to that of the mains voltage. The identification plate is found on the appliance.
60. In the event of any abnormal situations immediately turn off the power and contact your dealer or service center .
61. Do not try to repair or make any part of the clipper by yourself. If there is anything irregular about the clipper, please have it inspected at an authorized service center .
62. Don't put heavy or hot objects on power cable and don't position base of the product and its cable near hot sources. Cables could be damaged.

FUNCTIONS

1. The principle of humidification by cooling, track cooling water from the water tank by water pump to spray on porous matter, after reaching the top, the cooling water will flow through wetted pad, then (allowed off) wind cool air reaching the wetted pad by rotational wind wheel.
2. Electronics control: safe and durable, have an attractive appearance.
3. Adjustable speed: have three speed, low, medium, high.
4. Wind type: nature wind, normal wind, sleeping wind.
5. Humidification function: the appliance adopts ice crystal refrigeration and humidification technology, it can cut down the temperature of air and raise relative humidity, prevent it from air drying.
6. Deliver wind at wide angle: swing the blades automatically, deliver wind at wide angle flutter. Also swing the blades horizontally by your hands, choose the wind direction up and down.
7. Remote control: For distance and wireless wide angle.
8. Removable air filter and cooling pad: easy to clean, can use soft brush and detergent.

OPERATION

Take out the product from gift box.

Mounting castors
Turn the air cooler upside down on a flat surface (preferably use a soft cloth surface to prevent the head of the machine from scratching).
Take out 4 castors, align the castor threaded shaft with the fixing hole at the bottom of the air cooler, and tighten with a wrench. With the brakes install in the front, without the brakes install at the back.

Fill the water tank
1. Pull out the water tank.
2. Fill the water tank with cold and clean water. Make sure that water level is between "Min" minimum level and "Max" maximum level.
3. To increase the cool effect insert the ice box in the water tank.Before use ice box, they must be filled by water and put in the refrigerator until they are completely frozen.
4. Close the water tank.

ATTENTION!

1. Make sure the product is unplugged from the mains before filling or refilling the water.
2. Only use water in the water tank. Do not add any chemicals ,oils or other additives.
3. Only use cold water in the water tank(previously boiled).
4. Make sure the water level in the water tank is between minimum level (indicated by "Min") and maximum level(indicated by "Max").

Pull out water tank | Put water or ice box | Install Pin

THE USE OF PRODUCT

Place the unit on a firm level surface and plug it into a socket. Power indicator light reminding this products in standby mode. Open the horizontal blades by hand. Then Turn on " ⏻ " button default setting is in middle speed, Turn it again products in standby .

1. **Speed key**: Press this key, automatically starting from med ,high ,low.
   → MEDI → HIGH → LOW →
2. **Mode key** : default setting is in normal wind. Press this key, automatically setting from normal wind, natural wind, sleep wind.
3. **Swing key** : press this key, the wind direction can swing flaty, and the swing indicator light is on. Press again to cancel the function.
   Swing the blades transversely by your hands, choosing the wind direction up or down.
4. **Timer key** : press this key, the timer from 0 to 8 hours, each pressing, 1hour.
5. **Cooling key** : press this key, start this function, and if you add the freezing ice crystal box in the water tank,air blow out temperature will much more cooling, it cancels this function when you press again (make sure water level is above min line).
6. **Humidification** : press this key, it only can start cool air unless the air speed (make sure water level is above min line).
7. **Ice key** : Press it to make the room air fresh, if no need this function ,press it again .



THE USE OF REMOTE CONTROLLER

The remote control use one button cells, model No. CR2025 (3V). We recommend the use of Lithium type battery for longer use.

Note: Please follow battery disposal instruction on battery packaging, or contact your local consulate for safety disposal of batteries.

THE USE OF ICE BOX

The ice crystal has a particular feature of keeping cool, it can absorb heat from water and reduce water temperature or the water tank to better environmental temperature, so the unit will be more cooler.
Using methods:
a. Add clean water to the ICE BOX, but not exceed the max level, then put into the refrigerating chamber of refrigerator to make sure that it ring absolutely.
b. After put clean water into the ice box, pls make sure it is closed tightly .
c. The contents of the ice box is to be kept away from children and are not consumable

STORAGE & MAINTAINENCE GUIDELINES

Read the detailed CLEANING & DRAINING THE WATER TANK instructions for your Air Cooler, located in the separate User Manual. Below is a general guideline for maintenance and storage of your Air Cooler.
WARNING: Always switch OFF the Air Cooler and unplug it from the electrical source before cleaning or maintenance. Cleaning At least once a week, drain the water tank completely and refill with fresh water. Doing this will greatly reduce mineral deposits and help to extend the life of the Honeycomb Cooling Media. End of Season Storage If the Air Cooler will not be used for a long time:
Make sure all parts are dry by running the Fan Only mode for about 30 minutes before storing (time depends on ambient humidity conditions). Switch OFF the Air Cooler and unplug from the power supply. Empty/drain all the water from the tank. Clean the water tank with a damp cloth to wipe away any dust or mineral deposits. Remove the Honeycomb Cooling Media from the Air Cooler and rinse under fresh water to remove dust and dirt. Replace the Honeycomb Cooling Media after they are clean and dry. To protect the unit from dust and scratches, cover with a clean cloth or plastic bag before storing. Coil the power cord and store it away from the floor to protect it.

CLEANING & DRAINING THE WATER TANK

If the cooler will not be used for a long period of time, please refer to the STORAGE & MAINTENANCE GUIDELINES located in the separate Safety & Maintenance Guide.

WARNING

Before cleaning the unit, switch the unit OFF and disconnect from the electrical socket. Move the unit to a location where the water can be drained. Remove the cap from the Drain plug located at the bottom of the unit. Allow the tank to empty. If pull out the water tank, pls loose the screw of pump first.

Refill the water tank with clean water and drain it completely. Refill the water tank with clean water, up to the maximum level. Use a damp cloth to remove the dirt and dust from the surface of the unit. Never use corrosive elements or chemicals to clean the product. When the product is not in use, store the unit in a dry place out of direct sunlight.

CLEANING THE HONEYCOMB COOLING

The appliance is supplied with a Honeycomb Cooling Media. The Honeycomb Cooling Media is located inside the Rear Grill. See Figure 1. Set instructions on how to remove them from the unit for cleaning and maintenance. Do not run the unit in COOL mode with clean water in the tank. You must refill the water tank and refill with fresh water, especially if the tank has not been cleaned in a long time.

Remove the screw | Take out the rear grill | Clean the Honeycomb

The cleaning frequency for the Honeycomb media depends on local air and water conditions. In areas where the mineral content of water is high, mineral deposits may build up on the Honeycomb Cooling Media and restrict air flow. Draining the water tank and refilling with fresh water at least once a week will help reduce mineral deposits. If mineral deposits remain on the Honeycomb Cooling Media, the media should be removed and washed under fresh water. The media should be cleaned every two months or sooner, depending on your conditions.
For best results allow the Honeycomb Cooling Media to dry after each use by turning off the cool function 15 minutes before turning the unit off.

SPECIFICATION

PRODUCT: AIR COOLER
MODEL: TZAZ10
POWER: 65W
VOLTAGE: 220-240V~ 50Hz

Information supplemente			
Maximum air flow	l	1,25	m³/min
Fan power input	P	0x121	W
Service value	Ev	0,34	(m³/min)²/P
Standby power consumption	Psb	0	W
Fan sound power level	Lwa	65,0	dB(A)
Maximum air velocity	C	1,23	m/s
Measuring standard of service value	IEC 60879:1986 (ed.1.0)/EN		
Contact details for obtaining more information	Dealer/Fornitore		

INFORMAZIONE SULLO STENDI
A norma del decreto legislativo 15 marzo 2010 n. 151 "Attuazione della direttiva 2002/96/CE RAEE
Il cestino del materiale elettrico sul prodotto indica che lo prodotto alla fine della propria durata non vanno raccolto separatamente dagli altri rifiuti.
1. Il cestino del materiale elettrico sul prodotto indica che lo prodotto alla fine della propria durata non vanno raccolto separatamente dagli altri rifiuti.
2. Il consumatore deve pertanto consegnare il materiale elettrico giunto a fine vita agli idonei centri di raccolta differenziata predisposti dai comuni o consegnare il materiale elettrico al rivenditore al momento dell'acquisto di una nuova apparecchiatura di tipo equivalente, in ragione di uno a uno.
3. L'adeguata raccolta differenziata per l'avvio successivo del apparecchiatura dismessa al riciclaggio, al trattamento e allo smaltimento ambientalmente compatibile contribuisce ad evitare possibili effetti negativi sull'ambiente e sulla salute e favorisce il riciclo del materiali di cui è composta l'apparecchiatura.
4. Lo smaltimento abusivo del prodotto da parte del possessore comporta l'applicazione delle sanzioni amministrative previste dalla normativa vigente.

Lange Distribution S.r.l. si riserva il diritto di apportare modifiche estetiche senza obbligo di preavviso.
Termozeta is an international trademark. Copyright © 1998. All rights reserved.
Lange Distribution S.r.l. - Via Tevere 26-20127 Milano Italy

INFORMATION FOR USERS
In accordance with European Directive 2012/19/EU on electric and electronic equipment and waste disposal
1. The barrel symbol on the cabinet ice shown on the equipment indicates that, at the end of its useful life, the product must be collected separately from waste.
2. Therefore, only products that have reached the end of their useful life must be given to waste disposal centers specializing in separate collection of waste electrical and electronic equipment, or be returned to the dealer at the time of purchasing new similar equipment, on a one for one basis.
3. The adequate separate collection for the subsequent start-up of the equipment sent to be recycled, treated and disposed of in an environmentally compatible way contributes to preventing possible negative effects on the environment and health and optimizes the recycling and reuse of components making up the equipment.
4. Abusive disposal of the product by the user involves application of the administrative sanctions according to the laws in force.

Lange Distribution S.r.l. - Via Tevere 26-20127 Milano Italy
Termozeta is an international trademark. Copyright © 1998. All rights reserved.
Lange Distribution S.r.l. - Via Tevere 26-20127 Milano Italy

PRODUCTED by Lange Distribution S.r.l.
Via Tevere 26
20127 Milano
Tel: +39 02.28399-1
Prodotto in Cina

145x210mm(20190223/YS1902221056)