

Manuale d'uso - Effizienz Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiência Energética / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual - Energieeffektivitet Руководство - Энергоэффективность / Käsiiraamat - Energiatõhususe / Rokasgrāmata - Energieeffektivitātes

Table with columns for model details (PF, S, M), technical specifications (AEchood, EEC, FDEhood, FDEC, LEhood, LEC, GFEhood, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, P0, Ps, F, EELhood, Qbep, Pbp, Qmax, Wbep, WL, Emiddle, Lwa), and performance metrics (PI, F, Qbep, Pbp, Qmax, Wbep, WL, Emiddle, Lwa). It includes multilingual descriptions and technical specifications for a range hood model.

