

# S66D

S66DJ2 foto / photo 9x13 1X  + 1X 

- DVD en foto opbergbox
- Box for DVD and photos
- Coffret pour DVD et photos
- Aufbewahrungsbox für DVD und Bilder



16x16x2,5 



13x13x3,2 

S66DJ3 foto / photo 8x8

- USB opbergbox (USB niet inbegrepen)
- Box for USB (USB not included)
- Coffret pour USB (USB pas inclus)
- Aufbewahrungsbox für USB (ohne USB geliefert)

S66DJ7 foto / photo 8x8

- USB opbergbox (USB niet inbegrepen)
- Box for USB (USB not included)
- Coffret pour USB (USB pas inclus)
- Aufbewahrungsbox für USB (ohne USB geliefert)




13x13x3,2 

S66DJ4 foto / photo 8x8

- USB opbergbox (USB niet inbegrepen)
- Box for USB (USB not included)
- Coffret pour USB (USB pas inclus)
- Aufbewahrungsbox für USB (ohne USB geliefert)



13x13x3,2 



S66DPB = pakket / paquet / set / Paket S66DJ3 - J4 - J7